



TORCUP

TU-11 Torque Conversion Chart

Imperial Conversion	
PSI	Ft-lbs
1,000	1198
1,200	1433
1,400	1668
1,600	1904
1,800	2139
2,000	2374
2,200	2612
2,400	2850
2,600	3088
2,800	3326
3,000	3564
3,200	3802
3,400	4041
3,600	4279
3,800	4518
4,000	4756
4,200	4990
4,400	5225
4,600	5459
4,800	5694
5,000	5928
5,200	6164
5,400	6400
5,600	6635
5,800	6871
6,000	7107
6,200	7348
6,400	7589
6,600	7831
6,800	8072
7,000	8313
7,200	8547
7,400	8781
7,600	9015
7,800	9249
8,000	9483
8,200	9727
8,400	9971
8,600	10214
8,800	10458
9,000	10702
9,200	10943
9,400	11184
9,600	11426
9,800	11667
10,000	11908

Metric Conversion	
Bar	Nm
69	1624
83	1943
97	2262
110	2581
124	2900
138	3219
152	3541
165	3864
179	4187
193	4509
207	4832
221	5155
234	5479
248	5802
262	6125
276	6448
290	6766
303	7084
317	7402
331	7719
345	8037
359	8357
372	8677
386	8996
400	9316
414	9636
427	9963
441	10290
455	10617
469	10944
483	11271
496	11588
510	11905
524	12223
538	12540
552	12857
565	13188
579	13518
593	13849
607	14179
621	14510
634	14837
648	15164
662	15491
676	15818
689	16145

For reference purposes only, please consult the calibration chart specific to your purchase or rental tool.

TorcUP, Inc.
1025 Conroy Place
Easton, Pa 18040

Tel:610-250-5800 Fax: 610-250-2700

