



TORCUP

TU-3 Torque Conversion Chart

Imperial Conversion	
PSI	Ft-lbs
1,000	347
1,200	414
1,400	481
1,600	547
1,800	614
2,000	681
2,200	748
2,400	816
2,600	883
2,800	951
3,000	1018
3,200	1085
3,400	1152
3,600	1220
3,800	1287
4,000	1354
4,200	1421
4,400	1487
4,600	1554
4,800	1620
5,000	1687
5,200	1754
5,400	1822
5,600	1889
5,800	1957
6,000	2024
6,200	2092
6,400	2160
6,600	2229
6,800	2297
7,000	2365
7,200	2432
7,400	2499
7,600	2565
7,800	2632
8,000	2699
8,200	2769
8,400	2838
8,600	2908
8,800	2977
9,000	3047
9,200	3115
9,400	3183
9,600	3251
9,800	3319
10,000	3387

Metric Conversion	
Bar	Nm
69	470
83	561
97	652
110	742
124	833
138	923
152	1015
165	1106
179	1197
193	1289
207	1380
221	1471
234	1562
248	1654
262	1745
276	1836
290	1926
303	2016
317	2107
331	2197
345	2287
359	2379
372	2470
386	2561
400	2653
414	2744
427	2837
441	2929
455	3022
469	3114
483	3207
496	3297
510	3388
524	3478
538	3569
552	3659
565	3754
579	3848
593	3942
607	4037
621	4131
634	4223
648	4316
662	4408
676	4500
689	4592

For reference purposes only, please consult the calibration chart specific to your purchase or rental tool.

TorcUP, Inc.
1025 Conroy Place
Easton, Pa 18040

Tel:610-250-5800 Fax: 610-250-2700

