



# TORCUP

## TU-60 Torque Conversion Chart

Imperial Conversion	
PSI	Ft-lbs
1,000	6202
1,200	7422
1,400	8641
1,600	9861
1,800	11080
2,000	12300
2,200	13477
2,400	14654
2,600	15831
2,800	17008
3,000	18185
3,200	19378
3,400	20571
3,600	21763
3,800	22956
4,000	24149
4,200	25344
4,400	26538
4,600	27733
4,800	28927
5,000	30122
5,200	31317
5,400	32511
5,600	33706
5,800	34900
6,000	36095
6,200	37293
6,400	38491
6,600	39688
6,800	40886
7,000	42084
7,200	43282
7,400	44480
7,600	45678
7,800	46876
8,000	48074
8,200	49272
8,400	50470
8,600	51667
8,800	52865
9,000	54063
9,200	55260
9,400	56456
9,600	57653
9,800	58849
10,000	60046

Metric Conversion	
Bar	Nm
69	8409
83	10062
97	11716
110	13369
124	15023
138	16677
152	18272
165	19868
179	21464
193	23060
207	24656
221	26273
234	27890
248	29507
262	31124
276	32742
290	34361
303	35981
317	37601
331	39220
345	40840
359	42460
372	44079
386	45699
400	47319
414	48938
427	50562
441	52186
455	53810
469	55434
483	57058
496	58683
510	60307
524	61931
538	63555
552	65180
565	66804
579	68428
593	70052
607	71676
621	73300
634	74922
648	76544
662	78167
676	79789
689	81411

For reference purposes only, please consult the calibration chart specific to your purchase or rental tool.

TorcUP, Inc.  
1025 Conroy Place  
Easton, Pa 18040

Tel:610-250-5800 Fax: 610-250-2700

