



TORCUP

TU-7 Torque Conversion Chart

Imperial Conversion	
PSI	Ft-lbs
1,000	790
1,200	947
1,400	1104
1,600	1262
1,800	1419
2,000	1576
2,200	1734
2,400	1892
2,600	2050
2,800	2208
3,000	2366
3,200	2525
3,400	2683
3,600	2842
3,800	3000
4,000	3159
4,200	3317
4,400	3475
4,600	3632
4,800	3790
5,000	3948
5,200	4106
5,400	4265
5,600	4423
5,800	4582
6,000	4740
6,200	4901
6,400	5063
6,600	5224
6,800	5386
7,000	5547
7,200	5705
7,400	5863
7,600	6021
7,800	6179
8,000	6337
8,200	6505
8,400	6674
8,600	6842
8,800	7011
9,000	7179
9,200	7342
9,400	7505
9,600	7668
9,800	7831
10,000	7994

Metric Conversion	
Bar	Nm
69	1071
83	1284
97	1497
110	1710
124	1924
138	2137
152	2351
165	2565
179	2779
193	2994
207	3208
221	3423
234	3638
248	3853
262	4068
276	4283
290	4497
303	4711
317	4925
331	5139
345	5353
359	5568
372	5782
386	5997
400	6212
414	6427
427	6645
441	6864
455	7083
469	7302
483	7521
496	7735
510	7949
524	8163
538	8378
552	8592
565	8820
579	9048
593	9277
607	9505
621	9733
634	9954
648	10175
662	10396
676	10617
689	10838

For reference purposes only, please consult the calibration chart specific to your purchase or rental tool.

TorcUP, Inc.
1025 Conroy Place
Easton, Pa 18040

Tel: 610-250-5800 Fax: 610-250-2700

