



TORCUP

TXU-4 Torque Conversion Chart (Imperial)

	Imperial Conversion			Imperial Conversion	
	PSI	Ft-lbs		PSI	Ft-lbs
Hex Range 1" - 2 9/16"	1,000	422	Hex Range 2 5/8" - 3 1/8"	1,000	475
	1,200	502		1,200	565
	1,400	582		1,400	655
	1,600	663		1,600	745
	1,800	743		1,800	836
	2,000	823		2,000	926
	2,200	906		2,200	1019
	2,400	989		2,400	1112
	2,600	1072		2,600	1206
	2,800	1155		2,800	1299
	3,000	1238		3,000	1393
	3,200	1320		3,200	1484
	3,400	1401		3,400	1576
	3,600	1483		3,600	1668
	3,800	1564		3,800	1760
	4,000	1646		4,000	1852
	4,200	1726		4,200	1942
	4,400	1806		4,400	2032
	4,600	1887		4,600	2122
	4,800	1967		4,800	2212
	5,000	2047		5,000	2303
	5,200	2128		5,200	2393
	5,400	2209		5,400	2484
	5,600	2289		5,600	2575
	5,800	2370		5,800	2666
	6,000	2451		6,000	2757
	6,200	2533		6,200	2849
	6,400	2615		6,400	2942
	6,600	2698		6,600	3034
	6,800	2780		6,800	3127
	7,000	2862		7,000	3219
	7,200	2942		7,200	3309
	7,400	3021		7,400	3398
	7,600	3101		7,600	3488
7,800	3180	7,800	3577		
8,000	3260	8,000	3667		
8,200	3343	8,200	3761		
8,400	3426	8,400	3854		
8,600	3510	8,600	3948		
8,800	3593	8,800	4041		
9,000	3676	9,000	4135		
9,200	3758	9,200	4227		
9,400	3840	9,400	4319		
9,600	3922	9,600	4412		
9,800	4004	9,800	4504		
10,000	4086	10,000	4596		

For reference purposes only, please consult the calibration chart specific to your purchase or rental tool.



TORCUP

TXU-4 Torque Conversion Chart (Metric)

Metric Conversion	
Bar	Nm
69	572
83	681
97	790
110	898
124	1007
138	1116
152	1228
165	1341
179	1453
193	1566
207	1679
221	1789
234	1900
248	2010
262	2121
276	2232
290	2340
303	2449
317	2558
331	2667
345	2775
359	2885
372	2994
386	3104
400	3214
414	3323
427	3435
441	3546
455	3657
469	3769
483	3880
496	3988
510	4096
524	4204
538	4312
552	4420
565	4533
579	4646
593	4758
607	4871
621	4984
634	5095
648	5206
662	5318
676	5429
689	5540

Hex Range 27-65mm

Metric Conversion	
Bar	Nm
69	644
83	766
97	888
110	1011
124	1133
138	1255
152	1382
165	1508
179	1635
193	1761
207	1888
221	2013
234	2137
248	2261
262	2386
276	2510
290	2633
303	2755
317	2877
331	3000
345	3122
359	3245
372	3368
386	3492
400	3615
414	3738
427	3863
441	3989
455	4114
469	4239
483	4365
496	4486
510	4608
524	4729
538	4850
552	4972
565	5099
579	5226
593	5352
607	5479
621	5606
634	5731
648	5856
662	5981
676	6107
689	6232

Hex Range 66-80mm

For reference purposes only, please consult the calibration chart specific to your purchase or rental tool.