



TORQUE

TXU-8 Torque Conversion Chart (Imperial)

	Imperial Conversion			Imperial Conversion			Imperial Conversion	
	PSI	Ft-lbs		PSI	Ft-lbs		PSI	Ft-lbs
	Hex Range 1 7/8" - 3 1/8"	1,000		797	Hex Range 3 3/16" - 3 9/16"		1,000	842
1,200		957	1,200	1011		1,200	1174	
1,400		1117	1,400	1180		1,400	1370	
1,600		1277	1,600	1350		1,600	1567	
1,800		1437	1,800	1519		1,800	1763	
2,000		1597	2,000	1688		2,000	1960	
2,200		1758	2,200	1858		2,200	2157	
2,400		1918	2,400	2027		2,400	2353	
2,600		2079	2,600	2197		2,600	2550	
2,800		2239	2,800	2366		2,800	2747	
3,000		2400	3,000	2536		3,000	2944	
3,200		2559	3,200	2704		3,200	3140	
3,400		2719	3,400	2873		3,400	3335	
3,600		2878	3,600	3041		3,600	3531	
3,800		3037	3,800	3210		3,800	3726	
4,000		3197	4,000	3378		4,000	3922	
4,200		3354	4,200	3544		4,200	4114	
4,400		3511	4,400	3710		4,400	4307	
4,600		3668	4,600	3876		4,600	4500	
4,800		3825	4,800	4042		4,800	4693	
5,000		3982	5,000	4208		5,000	4885	
5,200		4143	5,200	4377		5,200	5082	
5,400		4303	5,400	4547		5,400	5279	
5,600		4463	5,600	4716		5,600	5475	
5,800		4623	5,800	4886		5,800	5672	
6,000		4784	6,000	5055		6,000	5869	
6,200		4946	6,200	5227		6,200	6068	
6,400		5109	6,400	5399		6,400	6267	
6,600		5272	6,600	5570		6,600	6467	
6,800		5434	6,800	5742		6,800	6666	
7,000	5597	7,000	5914	7,000	6866			
7,200	5756	7,200	6083	7,200	7062			
7,400	5916	7,400	6252	7,400	7258			
7,600	6076	7,600	6420	7,600	7454			
7,800	6236	7,800	6589	7,800	7650			
8,000	6395	8,000	6758	8,000	7846			
8,200	6564	8,200	6936	8,200	8052			
8,400	6732	8,400	7113	8,400	8258			
8,600	6900	8,600	7291	8,600	8464			
8,800	7068	8,800	7468	8,800	8670			
9,000	7236	9,000	7646	9,000	8877			
9,200	7393	9,200	7813	9,200	9070			
9,400	7551	9,400	7979	9,400	9263			
9,600	7709	9,600	8146	9,600	9457			
9,800	7866	9,800	8312	9,800	9650			
10,000	8024	10,000	8479	10,000	9844			

For reference purposes only, please consult the calibration chart specific to your purchase or rental tool.



TORCUP

TXU-8 Torque Conversion Chart (Metric)

Metric Conversion	
Bar	Nm
69	1080
83	1297
97	1515
110	1732
124	1949
138	2166
152	2383
165	2601
179	2819
193	3036
207	3254
221	3470
234	3686
248	3902
262	4118
276	4334
290	4547
303	4760
317	4973
331	5186
345	5399
359	5617
372	5834
386	6051
400	6269
414	6486
427	6706
441	6927
455	7147
469	7368
483	7588
496	7805
510	8021
524	8238
538	8454
552	8671
565	8899
579	9127
593	9355
607	9583
621	9810
634	10024
648	10238
662	10452
676	10665
689	10879

Hex Range 49-80mm

Metric Conversion	
Bar	Nm
69	1142
83	1371
97	1600
110	1830
124	2059
138	2289
152	2519
165	2749
179	2978
193	3208
207	3438
221	3667
234	3895
248	4123
262	4352
276	4580
290	4805
303	5030
317	5255
331	5480
345	5705
359	5935
372	6165
386	6394
400	6624
414	6854
427	7087
441	7320
455	7552
469	7785
483	8018
496	8247
510	8476
524	8705
538	8934
552	9163
565	9403
579	9644
593	9885
607	10126
621	10367
634	10592
648	10818
662	11044
676	11270
689	11496

Hex Range 81-90mm

Metric Conversion	
Bar	Nm
69	1325
83	1592
97	1858
110	2124
124	2391
138	2657
152	2924
165	3191
179	3458
193	3725
207	3992
221	4257
234	4522
248	4787
262	5052
276	5317
290	5578
303	5840
317	6101
331	6362
345	6624
359	6890
372	7157
386	7423
400	7690
414	7957
427	8227
441	8498
455	8768
469	9038
483	9309
496	9575
510	9840
524	10106
538	10372
552	10637
565	10917
579	11196
593	11476
607	11755
621	12035
634	12297
648	12559
662	12822
676	13084
689	13346

Hex Range 91-120mm

For reference purposes only, please consult the calibration chart specific to your purchase or rental tool.